


Find Help

- YOUR SPA TOUCH™ 4/4 +..... 2**
 - Touch To Start 2
 - Navigating Home 2
 - Reminders, Warnings, Errors 3
 - Features and Functionality 4
 - Quick Glance Screens 5
- PREPARE YOUR SPA 6**
 - Before You Soak 6
- PRIME THE PUMP 7**
- CONNECT YOUR SPA TOUCH 4/4 + . 8**
 - Register your Spa Touch 4/4+ 9
- UPDATE SOFTWARE 11**
- SET THE TIME 12**
- SET FILTER CYCLES..... 13**
- SET CLEANUP CYCLE 14**
- ADJUST WATER TEMPERATURE... 15**
- START SPA HOLD..... 16**
- TURN ON THE JETS 17**
- ADJUST SCREEN BRIGHTNESS..... 18**
- SET THE HEAT MODE..... 19**
 - Temperature Range 20
- SET LOCKS 21**
- SET LANGUAGE 22**
- DIAGNOSTICS 23**
 - Spa Information..... 23
- FCC AND NOTICES 24**



spatouch™ 4/4+

USER GUIDE

Find Help

- YOUR SPA TOUCH™ 4/4 +..... 2**
 - Touch To Start 2
 - Navigating Home 2
 - Reminders, Warnings, Errors 3
 - Features and Functionality 4
 - Quick Glance Screens 5
- PREPARE YOUR SPA 6**
 - Before You Soak 6
- PRIME THE PUMP 7**
- CONNECT YOUR SPA TOUCH 4/4 + . 8**
 - Register your Spa Touch 4/4+ 9
- UPDATE SOFTWARE 11**
- SET THE TIME 12**
- SET FILTER CYCLES..... 13**
- SET CLEANUP CYCLE 14**
- ADJUST WATER TEMPERATURE... 15**
- START SPA HOLD..... 16**
- TURN ON THE JETS 17**
- ADJUST SCREEN BRIGHTNESS..... 18**
- SET THE HEAT MODE..... 19**
 - Temperature Range 20
- SET LOCKS 21**
- SET LANGUAGE 22**
- DIAGNOSTICS 23**
 - Spa Information..... 23
- FCC AND NOTICES 24**

YOUR SPA TOUCH™ 4/4 +


TOUCH TO START

Your Spa Touch 4 and Spa Touch 4+ (Spa Touch 4/4+) display by touching anywhere on the screen. Use your fingertip to touch, scroll, slide or swipe to activate the various icons and images on the panel screen.

NOTE: Features and functions available are shown here. Your system display may vary.


To "wake up" SpaTouch 4/4+:

- 1 Touch the SpaTouch 4/4+ Screen in Sleep Mode. The **Splash Screen** displays, and then the **Home Screen** displays.



NAVIGATING HOME

The Spa Touch 4/4+ **Home Screen** is your central connection to all your spa offers.



- 2 Touch the **arrows** ◀ ▶ to advance through your connected spa selections and the **Home Screen**.

The bottom row of functions are accessible when displayed for quick access. See "[Quick Glance Screens](#)" on page 5 to learn more about Relax Mode.

Find Help


- YOUR SPA TOUCH™ 4/4 +..... 2**
 - Touch To Start 2
 - Navigating Home 2
 - Reminders, Warnings, Errors 3
 - Features and Functionality 4
 - Quick Glance Screens 5
- PREPARE YOUR SPA 6**
 - Before You Soak 6
- PRIME THE PUMP 7**
- CONNECT YOUR SPA TOUCH 4/4 + . 8**
 - Register your Spa Touch 4/4+ 9
- UPDATE SOFTWARE 11**
- SET THE TIME 12**
- SET FILTER CYCLES..... 13**
- SET CLEANUP CYCLE 14**
- ADJUST WATER TEMPERATURE... 15**
- START SPA HOLD..... 16**
- TURN ON THE JETS 17**
- ADJUST SCREEN BRIGHTNESS..... 18**
- SET THE HEAT MODE..... 19**
 - Temperature Range 20
- SET LOCKS 21**
- SET LANGUAGE 22**
- DIAGNOSTICS 23**
 - Spa Information..... 23
- FCC AND NOTICES 24**

YOUR SPA TOUCH 4/4 + (CONTINUED)

REMINDERS, WARNINGS, ERRORS

NOTE: Features and functions available are shown here. Your system display may vary.

Interactive messages display to alert you of status and changing conditions that affect your spa's maintenance or performance. See your product manual for more information.





Message Buttons

Button	What it means	Example Messages
	Informational and Instructive messages.	"Clean the filter"
	Alert to possible damage to product or property if you fail to comply with the cautionary statements that accompany it.	"The pH is high." "Program memory failure."
	Warning, whether mechanical or system related, which may affect operation and requires immediate attention.	"Insufficient water flow detected 3 times while attempting to heat. Service needed."

Message Display Samples

Each message describes the purpose and steps to take, depending on the spa environment.

NOTE: iMessages ⓘ are interactive and when touched display more details.



Touch to close

Touch for more details

Touch to close message

Find Help


- YOUR SPA TOUCH™ 4/4 +..... 2**
 - Touch To Start 2
 - Navigating Home 2
 - Reminders, Warnings, Errors 3
 - Features and Functionality 4
 - Quick Glance Screens 5
- PREPARE YOUR SPA 6**
 - Before You Soak 6
- PRIME THE PUMP 7**
- CONNECT YOUR SPA TOUCH 4/4 + . 8**
 - Register your Spa Touch 4/4+ 9
- UPDATE SOFTWARE 11**
- SET THE TIME 12**
- SET FILTER CYCLES..... 13**
- SET CLEANUP CYCLE 14**
- ADJUST WATER TEMPERATURE... 15**
- START SPA HOLD..... 16**
- TURN ON THE JETS 17**
- ADJUST SCREEN BRIGHTNESS..... 18**
- SET THE HEAT MODE..... 19**
 - Temperature Range 20
- SET LOCKS 21**
- SET LANGUAGE 22**
- DIAGNOSTICS 23**
 - Spa Information..... 23
- FCC AND NOTICES 24**

YOUR SPA TOUCH 4/4 + (CONTINUED)


FEATURES AND FUNCTIONALITY

NOTE: Features and functions available are shown here. Your system display may vary.

Touch your available features repeatedly to activate on and off.



Where available, spa systems using multispeed pumps display these active indicators as you touch repeatedly.



Find Help


- YOUR SPA TOUCH™ 4/4 +..... 2**
 - Touch To Start 2
 - Navigating Home 2
 - Reminders, Warnings, Errors 3
 - Features and Functionality 4
 - Quick Glance Screens 5
- PREPARE YOUR SPA 6**
 - Before You Soak 6
- PRIME THE PUMP 7**
- CONNECT YOUR SPA TOUCH 4/4 + . 8**
 - Register your Spa Touch 4/4+ 9
- UPDATE SOFTWARE 11**
- SET THE TIME 12**
- SET FILTER CYCLES..... 13**
- SET CLEANUP CYCLE 14**
- ADJUST WATER TEMPERATURE... 15**
- START SPA HOLD..... 16**
- TURN ON THE JETS 17**
- ADJUST SCREEN BRIGHTNESS..... 18**
- SET THE HEAT MODE..... 19**
 - Temperature Range 20
- SET LOCKS 21**
- SET LANGUAGE 22**
- DIAGNOSTICS 23**
 - Spa Information..... 23
- FCC AND NOTICES 24**

YOUR SPA TOUCH 4/4 + (CONTINUED)


QUICK GLANCE SCREENS

NOTE: Features and functions available are shown here. Your system display may vary.

- 1 The **Quick Glance Screen** displays a simple time and current water temperature status.



The **Relax Screen** displays, which also occurs after no screen interaction for an extended period of time.



- **All Off*** - 1-touch control that turns off all currently active functionality, including the heater and pump, lights and music, where available. To restart, touch **Home** to access the **Spa Selection Screen** and touch features and functions on. See "Features and Functionality" on page 4 for more information.

* Circulation pump (Circ pump) remains on where available.

Find Help

- YOUR SPA TOUCH™ 4/4 +..... 2**
 - Touch To Start 2
 - Navigating Home 2
 - Reminders, Warnings, Errors 3
 - Features and Functionality 4
 - Quick Glance Screens 5
- PREPARE YOUR SPA 6**
 - Before You Soak 6
- PRIME THE PUMP 7**
- CONNECT YOUR SPA TOUCH 4/4 + . 8**
 - Register your Spa Touch 4/4+ 9
- UPDATE SOFTWARE 11**
- SET THE TIME 12**
- SET FILTER CYCLES..... 13**
- SET CLEANUP CYCLE 14**
- ADJUST WATER TEMPERATURE... 15**
- START SPA HOLD..... 16**
- TURN ON THE JETS 17**
- ADJUST SCREEN BRIGHTNESS..... 18**
- SET THE HEAT MODE..... 19**
 - Temperature Range 20
- SET LOCKS 21**
- SET LANGUAGE 22**
- DIAGNOSTICS 23**
 - Spa Information..... 23
- FCC AND NOTICES 24**

PREPARE YOUR SPA

NOTE: Features and functions available are shown here. Your system settings display may vary.


BEFORE YOU SOAK

IMPORTANT: Your spa requires essential settings to provide optimal performance.


Follow these steps to prepare your spa for first use:

- 1 "Prime The Pump" on page 7.
- 2 "Connect your Spa Touch 4/4 +" on page 8.
- 3 "Update Software" on page 11.
- 4 "Set The Time" on page 12.
- 5 "Set Filter Cycles" on page 13.
- 6 "Adjust Water Temperature" on page 15.
- 7 "Turn On The Jets" on page 17.

Find all settings from the **Home Screen > Settings** ⚙️.



Home Screen



Settings Menu Screen

After you complete these essential settings, customize your preferences to suit your schedule, and have your spa ready and waiting for your enjoyment.

Find Help

- YOUR SPA TOUCH™ 4/4 +..... 2**
 - Touch To Start 2
 - Navigating Home 2
 - Reminders, Warnings, Errors 3
 - Features and Functionality 4
 - Quick Glance Screens 5
- PREPARE YOUR SPA 6**
 - Before You Soak 6
- PRIME THE PUMP 7**
- CONNECT YOUR SPA TOUCH 4/4 + . 8**
 - Register your Spa Touch 4/4+ 9
- UPDATE SOFTWARE 11**
- SET THE TIME 12**
- SET FILTER CYCLES..... 13**
- SET CLEANUP CYCLE 14**
- ADJUST WATER TEMPERATURE... 15**
- START SPA HOLD..... 16**
- TURN ON THE JETS 17**
- ADJUST SCREEN BRIGHTNESS..... 18**
- SET THE HEAT MODE..... 19**
 - Temperature Range 20
- SET LOCKS 21**
- SET LANGUAGE 22**
- DIAGNOSTICS 23**
 - Spa Information..... 23
- FCC AND NOTICES 24**


PRIME THE PUMP

Priming is a 4-minute window of time that occurs after initially powering up at installation or an outage, and is used to help clear waterflow of trapped air or possible obstructions that can strain the system.

NOTE: Features and functions available are shown here. Your system settings display may vary.

To prime the pump:

- 1 After the Spa Touch 4/4+ powers up, watch for the prompt, "Prime your spa."
The message to prime your spa displays.



Priming Message

- 2 Touch each jet on and then off to see that air bubbles are purged and water flows smoothly.
The jets start up and clear air bubbles from the pipes.

NOTE: During priming, you can also touch other water features lit on the panel.

After priming, the spa screen displays active features your panel controls.

Find Help

- YOUR SPA TOUCH™ 4/4 +..... 2**
 - Touch To Start 2
 - Navigating Home 2
 - Reminders, Warnings, Errors 3
 - Features and Functionality 4
 - Quick Glance Screens 5
- PREPARE YOUR SPA 6**
 - Before You Soak 6
- PRIME THE PUMP 7**
- CONNECT YOUR SPA TOUCH 4/4 + . 8**
 - Register your Spa Touch 4/4+ 9
- UPDATE SOFTWARE 11**
- SET THE TIME 12**
- SET FILTER CYCLES..... 13**
- SET CLEANUP CYCLE 14**
- ADJUST WATER TEMPERATURE... 15**
- START SPA HOLD..... 16**
- TURN ON THE JETS 17**
- ADJUST SCREEN BRIGHTNESS..... 18**
- SET THE HEAT MODE..... 19**
 - Temperature Range 20
- SET LOCKS 21**
- SET LANGUAGE 22**
- DIAGNOSTICS 23**
 - Spa Information..... 23
- FCC AND NOTICES 24**

CONNECT YOUR SPA TOUCH 4/4 +


IMPORTANT: Connecting your Spa Touch 4/4+ to your Wi-Fi delivers timely updates your system needs for ongoing improvements.

BEFORE YOU BEGIN: Have your Wi-Fi network and password available.

CONNECT WI-FI


To connect to Wi-Fi:

- 1 From Home, touch **Settings** ⚙️, and then scroll and touch **Wi-Fi**. The **Wi-Fi Screen** displays "Not Connected" with available networks.




Settings Menu

- 2 Scroll and touch your Wi-Fi network to connect your spa panel.



Wi-Fi Screen

A keyboard displays for you to type your network password.



Enter Password Screen

- 3 Enter your network password and touch **Save**. "Attempting to connect" displays, and upon connection, the **Wi-Fi Screen** displays with your newly selected network.

Find Help

- YOUR SPA TOUCH™ 4/4 +..... 2**
 - Touch To Start 2
 - Navigating Home 2
 - Reminders, Warnings, Errors 3
 - Features and Functionality 4
 - Quick Glance Screens 5
- PREPARE YOUR SPA 6**
 - Before You Soak 6
- PRIME THE PUMP 7**
- CONNECT YOUR SPA TOUCH 4/4 + . 8**
 - Register your Spa Touch 4/4+ 9
- UPDATE SOFTWARE 11**
- SET THE TIME 12**
- SET FILTER CYCLES..... 13**
- SET CLEANUP CYCLE 14**
- ADJUST WATER TEMPERATURE... 15**
- START SPA HOLD..... 16**
- TURN ON THE JETS 17**
- ADJUST SCREEN BRIGHTNESS..... 18**
- SET THE HEAT MODE..... 19**
 - Temperature Range 20
- SET LOCKS 21**
- SET LANGUAGE 22**
- DIAGNOSTICS 23**
 - Spa Information..... 23
- FCC AND NOTICES 24**

CONNECT YOUR SPA TOUCH 4/4 + (CONTINUED)


4 Touch **Back** < to return to the Settings Menu.

REGISTER YOUR SPA TOUCH 4/4+

NOTE: This step is needed to establish your ControlMySpa (CMS) account, and give you access to use the CMS App from your mobile device. You will need your 8-digit CMS Code from your spa dealer.


To register your Spa Touch 4/4+:

5 From the Settings Menu, touch **ControlMySpa**.




Settings Menu

The **ControlMySpa Screen** displays.



6 Touch the **Edit** icon , and the ControlMySpa keyboard displays.




Find Help

- YOUR SPA TOUCH™ 4/4 +..... 2**
 - Touch To Start 2
 - Navigating Home 2
 - Reminders, Warnings, Errors 3
 - Features and Functionality 4
 - Quick Glance Screens 5
- PREPARE YOUR SPA 6**
 - Before You Soak 6
- PRIME THE PUMP 7**
- CONNECT YOUR SPA TOUCH 4/4 + . 8**
 - Register your Spa Touch 4/4+ 9
- UPDATE SOFTWARE 11**
- SET THE TIME 12**
- SET FILTER CYCLES..... 13**
- SET CLEANUP CYCLE 14**
- ADJUST WATER TEMPERATURE... 15**
- START SPA HOLD..... 16**
- TURN ON THE JETS 17**
- ADJUST SCREEN BRIGHTNESS..... 18**
- SET THE HEAT MODE..... 19**
 - Temperature Range 20
- SET LOCKS 21**
- SET LANGUAGE 22**
- DIAGNOSTICS 23**
 - Spa Information..... 23
- FCC AND NOTICES 24**

CONNECT YOUR SPA TOUCH 4/4 + (CONTINUED)


- 7 Enter the CMS Code supplied by your spa dealer, and then touch **Save**.
The **ControlMySpa Screen** displays a QR code you will use to pair your spa when you establish your **ControlMySpa App** account.
Leave the **ControlMySpa Screen** open on your panel to complete **Spa Account Setup**.



ControlMySpa Screen

Create a ControlMySpa Account

- 8 Using your mobile phone, go to your App store, and download **ControlMySpa**. (Works with iPhone models 8+ and up.)
- 9 Follow the in-app prompts to set up an account, and then **Setup Spa**. Be sure to set up your spa account "by QR code."
- 10 Use your phone's camera to scan the QR code displayed on the Spa Touch 4/4+ panel, and complete **Spa Account Setup**.



- 11 **IMPORTANT:** When you see "Account Setup Successful" on your mobile device, check your email to authenticate your account and complete this step.

Find Help


- YOUR SPA TOUCH™ 4/4 +..... 2**
 - Touch To Start 2
 - Navigating Home 2
 - Reminders, Warnings, Errors 3
 - Features and Functionality 4
 - Quick Glance Screens 5
- PREPARE YOUR SPA 6**
 - Before You Soak 6
- PRIME THE PUMP 7**
- CONNECT YOUR SPA TOUCH 4/4 + . 8**
 - Register your Spa Touch 4/4+ 9
- UPDATE SOFTWARE 11**
- SET THE TIME 12**
- SET FILTER CYCLES..... 13**
- SET CLEANUP CYCLE 14**
- ADJUST WATER TEMPERATURE... 15**
- START SPA HOLD..... 16**
- TURN ON THE JETS 17**
- ADJUST SCREEN BRIGHTNESS..... 18**
- SET THE HEAT MODE..... 19**
 - Temperature Range 20
- SET LOCKS 21**
- SET LANGUAGE 22**
- DIAGNOSTICS 23**
 - Spa Information..... 23
- FCC AND NOTICES 24**

UPDATE SOFTWARE

IMPORTANT: Be sure to update software for your Spa Touch 4/4+, and keep your system current.

To check for software updates:


1 From Home, touch **Settings** , then **Software Update**.



Settings Menu


The **Software Update Screen** displays.

2 Touch **Update**.



Settings Menu

The Status displays "Getting Updates", "Downloading", "Installing", and "Current" when the update is complete.



Software Update Screen

Find Help

- YOUR SPA TOUCH™ 4/4 +..... 2**
 - Touch To Start 2
 - Navigating Home 2
 - Reminders, Warnings, Errors 3
 - Features and Functionality 4
 - Quick Glance Screens 5
- PREPARE YOUR SPA 6**
 - Before You Soak 6
- PRIME THE PUMP 7**
- CONNECT YOUR SPA TOUCH 4/4 + . 8**
 - Register your Spa Touch 4/4+ 9
- UPDATE SOFTWARE 11**
- SET THE TIME 12**
- SET FILTER CYCLES..... 13**
- SET CLEANUP CYCLE 14**
- ADJUST WATER TEMPERATURE... 15**
- START SPA HOLD..... 16**
- TURN ON THE JETS 17**
- ADJUST SCREEN BRIGHTNESS..... 18**
- SET THE HEAT MODE..... 19**
 - Temperature Range 20
- SET LOCKS 21**
- SET LANGUAGE 22**
- DIAGNOSTICS 23**
 - Spa Information..... 23
- FCC AND NOTICES 24**


SET THE TIME

The time you set displays on the **Quick Glance** and **Relax Screens**, and becomes your system’s time, used to automate the duration of other functions, such as filter cycles, activation and water maintenance for reliable performance.

IMPORTANT: A message button ⓘ displays when the time needs to be set, and turns off after you set the time.


To set the time:

- 1 From the **Home Screen**, touch **Settings** ⚙, then **Time**.



Settings Menu

The **Time Screen** displays.



Time Screen

- 2 Touch buttons and arrows to the current time and **Save**. The new time is saved in the system.

Find Help


- YOUR SPA TOUCH™ 4/4 +..... 2**
 - Touch To Start 2
 - Navigating Home 2
 - Reminders, Warnings, Errors 3
 - Features and Functionality 4
 - Quick Glance Screens 5
- PREPARE YOUR SPA 6**
 - Before You Soak 6
- PRIME THE PUMP 7**
- CONNECT YOUR SPA TOUCH 4/4 + . 8**
 - Register your Spa Touch 4/4+ 9
- UPDATE SOFTWARE 11**
- SET THE TIME 12**
- SET FILTER CYCLES..... 13**
- SET CLEANUP CYCLE 14**
- ADJUST WATER TEMPERATURE... 15**
- START SPA HOLD..... 16**
- TURN ON THE JETS 17**
- ADJUST SCREEN BRIGHTNESS..... 18**
- SET THE HEAT MODE..... 19**
 - Temperature Range 20
- SET LOCKS 21**
- SET LANGUAGE 22**
- DIAGNOSTICS 23**
 - Spa Information..... 23
- FCC AND NOTICES 24**

SET FILTER CYCLES

Daily filtration assures your spa is operating as designed.

To set the filter cycle times:


1 From the **Home Screen**, touch **Settings** ⚙, then **Filter Cycles**.



Filter Cycles

The **Filter Cycles Screen** displays the number of cycles you can schedule.

2 Touch **Filter Cycle 1**.



Filter Cycles

3 Touch **Start** and touch arrows to set the filter cycle starting time. Your desired filter cycle duration adjusts as you make changes.

4 Touch **End** and touch arrows to set the filter cycle ending time. Your desired filter cycle duration adjusts as you change it.

5 Touch **Save**. The **Filter Cycles Screen** displays.

6 Repeat steps to set additional filter cycles displayed.

7 Touch **Back** < to return to the **Home Screen**.

Find Help

- YOUR SPA TOUCH™ 4/4 +..... 2**
 - Touch To Start 2
 - Navigating Home 2
 - Reminders, Warnings, Errors 3
 - Features and Functionality 4
 - Quick Glance Screens 5
- PREPARE YOUR SPA 6**
 - Before You Soak 6
- PRIME THE PUMP 7**
- CONNECT YOUR SPA TOUCH 4/4 + . 8**
 - Register your Spa Touch 4/4+ 9
- UPDATE SOFTWARE 11**
- SET THE TIME 12**
- SET FILTER CYCLES..... 13**
- SET CLEANUP CYCLE 14**
- ADJUST WATER TEMPERATURE... 15**
- START SPA HOLD..... 16**
- TURN ON THE JETS 17**
- ADJUST SCREEN BRIGHTNESS..... 18**
- SET THE HEAT MODE..... 19**
 - Temperature Range 20
- SET LOCKS 21**
- SET LANGUAGE 22**
- DIAGNOSTICS 23**
 - Spa Information..... 23
- FCC AND NOTICES 24**

SET CLEANUP CYCLE

Adjust your cleanup cycle duration for the pump to run, and keep the water clean and ready to enjoy after each use.

To set the cleanup cycle times:

1 From the **Home Screen**, touch **Settings** ⚙, then **Cleanup Cycle**.



Cleanup Cycle

The **Cleanup Cycle Screen** displays the duration of time the pump will run after use.

2 Touch the arrows to adjust to the desired duration up to 4 hours.

3 Touch **Save**.
The new cleanup cycle duration is set.

4 Touch **Back** < to return to the **Home Screen**.

Find Help


- YOUR SPA TOUCH™ 4/4 +..... 2**
 - Touch To Start 2
 - Navigating Home 2
 - Reminders, Warnings, Errors 3
 - Features and Functionality 4
 - Quick Glance Screens 5
- PREPARE YOUR SPA 6**
 - Before You Soak 6
- PRIME THE PUMP 7**
- CONNECT YOUR SPA TOUCH 4/4 + . 8**
 - Register your Spa Touch 4/4+ 9
- UPDATE SOFTWARE 11**
- SET THE TIME 12**
- SET FILTER CYCLES..... 13**
- SET CLEANUP CYCLE 14**
- ADJUST WATER TEMPERATURE... 15**
- START SPA HOLD..... 16**
- TURN ON THE JETS 17**
- ADJUST SCREEN BRIGHTNESS..... 18**
- SET THE HEAT MODE..... 19**
 - Temperature Range 20
- SET LOCKS 21**
- SET LANGUAGE 22**
- DIAGNOSTICS 23**
 - Spa Information..... 23
- FCC AND NOTICES 24**

ADJUST WATER TEMPERATURE

Find your current water temperature displayed in large numbers on the Water Temperature reading of the **Home Screen**.


To set the desired water temperature:

- 1 From the **Home Screen**, touch the **Water Temperature** area of the screen.



Home Screen

The **Desired Temperature Screen** displays.



Desired Temperature Screen

- 2 Touch the **plus +** and **minus -** signs or slide the bar along the bottom of the screen for your desired temperature.
- 3 Touch the unit of measure, upper right, to change between Fahrenheit (°F) or Celsius (°C) as the water temperature unit of measure.
The system begins to adjust to the newly set temperature.
- 4 Touch **Back <** to return to the **Home Screen**.

Find Help


- YOUR SPA TOUCH™ 4/4 +..... 2**
 - Touch To Start 2
 - Navigating Home 2
 - Reminders, Warnings, Errors 3
 - Features and Functionality 4
 - Quick Glance Screens 5
- PREPARE YOUR SPA 6**
 - Before You Soak 6
- PRIME THE PUMP 7**
- CONNECT YOUR SPA TOUCH 4/4 + . 8**
 - Register your Spa Touch 4/4+ 9
- UPDATE SOFTWARE 11**
- SET THE TIME 12**
- SET FILTER CYCLES..... 13**
- SET CLEANUP CYCLE 14**
- ADJUST WATER TEMPERATURE... 15**
- START SPA HOLD..... 16**
- TURN ON THE JETS 17**
- ADJUST SCREEN BRIGHTNESS..... 18**
- SET THE HEAT MODE..... 19**
 - Temperature Range 20
- SET LOCKS 21**
- SET LANGUAGE 22**
- DIAGNOSTICS 23**
 - Spa Information..... 23
- FCC AND NOTICES 24**

START SPA HOLD

Use this setting for temporary servicing or maintenance. When started, it pauses all spa activities for 1 hour.


To start Spa Hold:

1 From the **Home Screen**, touch **Settings** ⚙️.



Home Screen


The **Settings Menu** displays.



Settings Menu

2 Scroll and touch **Spa Hold**.


The **Spa Hold Screen** displays.



Start Hold

3 Touch **Start Hold**

The Spa pauses displaying the minutes remaining on hold.



Start Hold Active

4 You can end the hold by touching **Exit**.

Find Help

- YOUR SPA TOUCH™ 4/4 +..... 2**
 - Touch To Start 2
 - Navigating Home 2
 - Reminders, Warnings, Errors 3
 - Features and Functionality 4
 - Quick Glance Screens 5
- PREPARE YOUR SPA 6**
 - Before You Soak 6
- PRIME THE PUMP 7**
- CONNECT YOUR SPA TOUCH 4/4 + . 8**
 - Register your Spa Touch 4/4+ 9
- UPDATE SOFTWARE 11**
- SET THE TIME 12**
- SET FILTER CYCLES..... 13**
- SET CLEANUP CYCLE 14**
- ADJUST WATER TEMPERATURE... 15**
- START SPA HOLD..... 16**
- TURN ON THE JETS 17**
- ADJUST SCREEN BRIGHTNESS..... 18**
- SET THE HEAT MODE..... 19**
 - Temperature Range 20
- SET LOCKS 21**
- SET LANGUAGE 22**
- DIAGNOSTICS 23**
 - Spa Information..... 23
- FCC AND NOTICES 24**


TURN ON THE JETS

NOTE: Features and functions available are shown here. Your system display may vary.

Turning on the jets provide the water pressure and motion for an enhanced, therapeutic soak.

To turn on the jets:


- 1 From the **Home Screen**, touch the available **Jet**  to activate, and touch the arrow  to see more features.



Home Screen

The spa features display with additional components connected to your system.

- 2 Touch on each jet for as many jets you want to activate, and the desired speed your system provides.



Spa Selections

- 3 Touch the **arrows**   to display the **Home Screen**.

Find Help


- YOUR SPA TOUCH™ 4/4 +..... 2**
 - Touch To Start 2
 - Navigating Home 2
 - Reminders, Warnings, Errors 3
 - Features and Functionality 4
 - Quick Glance Screens 5
- PREPARE YOUR SPA 6**
 - Before You Soak 6
- PRIME THE PUMP 7**
- CONNECT YOUR SPA TOUCH 4/4 + . 8**
 - Register your Spa Touch 4/4+ 9
- UPDATE SOFTWARE 11**
- SET THE TIME 12**
- SET FILTER CYCLES..... 13**
- SET CLEANUP CYCLE 14**
- ADJUST WATER TEMPERATURE... 15**
- START SPA HOLD..... 16**
- TURN ON THE JETS 17**
- ADJUST SCREEN BRIGHTNESS..... 18**
- SET THE HEAT MODE..... 19**
 - Temperature Range 20
- SET LOCKS 21**
- SET LANGUAGE 22**
- DIAGNOSTICS 23**
 - Spa Information..... 23
- FCC AND NOTICES 24**

ADJUST SCREEN BRIGHTNESS

Adjust your panel display brightness.

To change the display brightness:


- 1 From the **Home Screen**, **Settings** ⚙, touch



Panel Settings

Panel Settings.

The **Screen Brightness Screen** displays with the brightness slider along the screen bottom.



Screen Brightness

- 2 Touch the **plus +** and **minus —** signs or slide the bar on the screen to adjust your desired level of brightness.
- 3 Touch **Home** 🏠 to return to the **Home Screen**.

Find Help

- YOUR SPA TOUCH™ 4/4 +..... 2**
 - Touch To Start 2
 - Navigating Home 2
 - Reminders, Warnings, Errors 3
 - Features and Functionality 4
 - Quick Glance Screens 5
- PREPARE YOUR SPA 6**
 - Before You Soak 6
- PRIME THE PUMP 7**
- CONNECT YOUR SPA TOUCH 4/4 + . 8**
 - Register your Spa Touch 4/4+ 9
- UPDATE SOFTWARE 11**
- SET THE TIME 12**
- SET FILTER CYCLES..... 13**
- SET CLEANUP CYCLE 14**
- ADJUST WATER TEMPERATURE... 15**
- START SPA HOLD..... 16**
- TURN ON THE JETS 17**
- ADJUST SCREEN BRIGHTNESS..... 18**
- SET THE HEAT MODE..... 19**
 - Temperature Range 20
- SET LOCKS 21**
- SET LANGUAGE 22**
- DIAGNOSTICS 23**
 - Spa Information 23
- FCC AND NOTICES 24**


SET THE HEAT MODE

NOTE: Features and functions available are shown here. Your system display may vary.

Keep your spa heated with these options: Run the spa as continuously regulating heat in a Ready state or as energy efficient in a Rest state.


To change the heat mode:

- 1 From the **Home Screen**, touch **Settings** ⚙️, then Heat Mode. The **Heat Mode Screen** displays.



Home Screen

- 2 Touch buttons to change the Heat Mode.



Heat Mode

Options are:

Ready - Regulates temperature continuously, and best for frequent, scheduled use.

Rest - Regulates temperature only during filter cycles.

Ready-In-Rest - When your spa is in Rest Mode, and you touch Jet 1 🌊, the system switches to Ready-In-Rest Mode and heats the water to the desired temperature for one hour. Then, the spa returns to Rest Mode.

NOTE: To cancel Ready-In-Rest and return back to Rest Mode within the hour, perform step 2 and touch Ready button.

- 3 Touch **Home** 🏠 to return to the **Home Screen**.

Find Help

- YOUR SPA TOUCH™ 4/4 +..... 2**
 - Touch To Start 2
 - Navigating Home 2
 - Reminders, Warnings, Errors 3
 - Features and Functionality 4
 - Quick Glance Screens 5
- PREPARE YOUR SPA 6**
 - Before You Soak 6
- PRIME THE PUMP 7**
- CONNECT YOUR SPA TOUCH 4/4 + . 8**
 - Register your Spa Touch 4/4+ 9
- UPDATE SOFTWARE 11**
- SET THE TIME 12**
- SET FILTER CYCLES..... 13**
- SET CLEANUP CYCLE 14**
- ADJUST WATER TEMPERATURE... 15**
- START SPA HOLD..... 16**
- TURN ON THE JETS 17**
- ADJUST SCREEN BRIGHTNESS..... 18**
- SET THE HEAT MODE..... 19**
 - Temperature Range 20
- SET LOCKS 21**
- SET LANGUAGE 22**
- DIAGNOSTICS 23**
 - Spa Information..... 23
- FCC AND NOTICES 24**

SET THE HEAT MODE (CONTINUED)


TEMPERATURE RANGE

Choose a range for your Desired Temperature setting, and that becomes the range displayed for setting spa water temperature. For example, choosing **High** may display a range from 80° F as the lowest degree, and 104° F as the highest of the High range.

NOTE: Your system's available ranges will vary. See your product manual for more information.


To change the range between High and Low:

- 1 From the Home Screen touch **Settings** ⚙️, then **Temperature Range**.



Settings Menu

The Temperature Range Screen displays.



Temperature Range

- 2 Touch either **High** or **Low** to choose what range displays in the Desired Temperature Screen.
Your selected range displays as the limits of your **Desired Temperature Screen**.
- 3 Touch **Home** 🏠 to return to the **Home Screen**.

Find Help


- YOUR SPA TOUCH™ 4/4 +..... 2**
 - Touch To Start 2
 - Navigating Home 2
 - Reminders, Warnings, Errors 3
 - Features and Functionality 4
 - Quick Glance Screens 5
- PREPARE YOUR SPA 6**
 - Before You Soak 6
- PRIME THE PUMP 7**
- CONNECT YOUR SPA TOUCH 4/4 + . 8**
 - Register your Spa Touch 4/4+ 9
- UPDATE SOFTWARE 11**
- SET THE TIME 12**
- SET FILTER CYCLES..... 13**
- SET CLEANUP CYCLE 14**
- ADJUST WATER TEMPERATURE... 15**
- START SPA HOLD..... 16**
- TURN ON THE JETS 17**
- ADJUST SCREEN BRIGHTNESS..... 18**
- SET THE HEAT MODE..... 19**
 - Temperature Range 20
- SET LOCKS 21**
- SET LANGUAGE 22**
- DIAGNOSTICS 23**
 - Spa Information..... 23
- FCC AND NOTICES 24**

SET LOCKS

Restrict panel access and changes to water temperature setting by setting the locks.

To change the security setting:


1 From the Home Screen, touch **Settings**  and scroll to touch **Locks**.



Settings Menu

The **Locks Screen** displays two types of locks you can set:

- **Settings Lock** - This lock restricts access to controls, including water temperature and scheduled maintenance functions, in order to maintain spa water quality and safety of your spa guests.
- **Panel Lock** - This lock restricts preferential and personalize settings that affect the individual spa experience, including what is displayed on the panel and panel access to make changes to settings.



Locks Screen

2 Touch the off / on toggle.  The message displays, "Press the lock icon to confirm".

3 Touch the **Lock** icon. The selected lock displays locked / unlocked.

4 Repeat steps 2 and 3 to change the setting again.

Find Help


- YOUR SPA TOUCH™ 4/4 +..... 2**
 - Touch To Start 2
 - Navigating Home 2
 - Reminders, Warnings, Errors 3
 - Features and Functionality 4
 - Quick Glance Screens 5
- PREPARE YOUR SPA 6**
 - Before You Soak 6
- PRIME THE PUMP 7**
- CONNECT YOUR SPA TOUCH 4/4 + . 8**
 - Register your Spa Touch 4/4+ 9
- UPDATE SOFTWARE 11**
- SET THE TIME 12**
- SET FILTER CYCLES..... 13**
- SET CLEANUP CYCLE 14**
- ADJUST WATER TEMPERATURE... 15**
- START SPA HOLD..... 16**
- TURN ON THE JETS 17**
- ADJUST SCREEN BRIGHTNESS..... 18**
- SET THE HEAT MODE..... 19**
 - Temperature Range 20
- SET LOCKS 21**
- SET LANGUAGE 22**
- DIAGNOSTICS 23**
 - Spa Information..... 23
- FCC AND NOTICES 24**

SET LANGUAGE

You can set a different language for the text in the panel screen display.

To set a different language:

- 1 From the **Home Screen**, touch **Settings**  and scroll to touch **Language**.



Settings Menu

The **Language Menu** displays.



Language Menu

- 2 Touch your desired language to use in the panel screens. Your selection is indicated in blue and the new language displays in the panel.
- 3 Touch **Back**  until the **Home Screen** displays in your selected language.

Find Help

- YOUR SPA TOUCH™ 4/4 +..... 2**
 - Touch To Start 2
 - Navigating Home 2
 - Reminders, Warnings, Errors 3
 - Features and Functionality 4
 - Quick Glance Screens 5
- PREPARE YOUR SPA 6**
 - Before You Soak 6
- PRIME THE PUMP 7**
- CONNECT YOUR SPA TOUCH 4/4 + . 8**
 - Register your Spa Touch 4/4+ 9
- UPDATE SOFTWARE 11**
- SET THE TIME 12**
- SET FILTER CYCLES..... 13**
- SET CLEANUP CYCLE 14**
- ADJUST WATER TEMPERATURE... 15**
- START SPA HOLD..... 16**
- TURN ON THE JETS 17**
- ADJUST SCREEN BRIGHTNESS..... 18**
- SET THE HEAT MODE..... 19**
 - Temperature Range 20
- SET LOCKS 21**
- SET LANGUAGE 22**
- DIAGNOSTICS 23**
 - Spa Information..... 23
- FCC AND NOTICES 24**


DIAGNOSTICS

Find your system settings and fault log record here.

To find your system Information:


- 1 From the **Home Screen**, touch **Settings** ⚙️, and scroll to touch **Diagnostics**.

The **Diagnostics Menu** displays access to two status pages:




Settings Menu

- 2 Touch **System Information** or **Fault Log** to see corresponding displays.



Diagnostics Menu

Your selected information displays.



System Information Example

SPA INFORMATION

To find your spa information:

- 1 From the **Home Screen**, touch the iMessage ⓘ .



The **Spa Information Screen** displays.

Find Help

YOUR SPA TOUCH™ 4/4 +.....	2
Touch To Start	2
Navigating Home	2
Reminders, Warnings, Errors	3
Features and Functionality	4
Quick Glance Screens	5
PREPARE YOUR SPA	6
Before You Soak	6
PRIME THE PUMP	7
CONNECT YOUR SPA TOUCH 4/4 + .	8
Register your Spa Touch 4/4+	9
UPDATE SOFTWARE	11
SET THE TIME	12
SET FILTER CYCLES.....	13
SET CLEANUP CYCLE	14
ADJUST WATER TEMPERATURE ...	15
START SPA HOLD.....	16
TURN ON THE JETS	17
ADJUST SCREEN BRIGHTNESS.....	18
SET THE HEAT MODE.....	19
Temperature Range	20
SET LOCKS	21
SET LANGUAGE	22
DIAGNOSTICS	23
Spa Information.....	23
FCC AND NOTICES	24

FCC AND NOTICES

RSS-Gen & RSS-247 statement:

This device complies with Industry Canada licence-exempt RSS standard(s). Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

RSS-102 Statement:

This equipment complies with Industry Canada radiation exposure limits set forth for an uncontrolled environment.

This device complies with Part 15 of the FCC Rules and Innovation, Science and Economic Development Canada license-exempt RSSs. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

FCC Caution:

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

FCC Statement:

"This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help."

This controller is not intended for transportable pool use.

Find Help

- YOUR SPA TOUCH™ 4/4 +..... 2**
 - Touch To Start 2
 - Navigating Home 2
 - Reminders, Warnings, Errors 3
 - Features and Functionality 4
 - Quick Glance Screens 5
- PREPARE YOUR SPA 6**
 - Before You Soak 6
- PRIME THE PUMP 7**
- CONNECT YOUR SPA TOUCH 4/4 + . 8**
 - Register your Spa Touch 4/4+ 9
- UPDATE SOFTWARE 11**
- SET THE TIME 12**
- SET FILTER CYCLES 13**
- SET CLEANUP CYCLE 14**
- ADJUST WATER TEMPERATURE... 15**
- START SPA HOLD..... 16**
- TURN ON THE JETS 17**
- ADJUST SCREEN BRIGHTNESS..... 18**
- SET THE HEAT MODE..... 19**
 - Temperature Range 20
- SET LOCKS 21**
- SET LANGUAGE 22**
- DIAGNOSTICS 23**
 - Spa Information..... 23
- FCC AND NOTICES 24**



BALBOA
A HELIOS TECHNOLOGIES COMPANY

Contact a sales representative
United States - sales@balboawater.com
Europe - europe@balboawater.com

Balboa
2020 Piper Ranch Road
San Diego, CA 92154
Phone: 714.384.0384
www.balboawater.com
Specifications subject to change without notice.



PLEASE
VISIT US