BP7 Tech Sheet - for Aftermarket use only

Customer: Balboa Water Group - Aftermarket Division

Part Number: G4361 800 Incoloy 4.0kW

G5361 800 Incoloy 5.5kW



Genuine Balboa Box Overlay

UL System Model (5.5kw): BP20-BP7-AU
UL System Model (4.0kw): BP20-BP7-AS
Software Version ID: M100 221 V55.0

Software Version: 55.0

File Name: BP1800_55.0_BP7.hex

Configuration Signature: FF69032A

Eng. Project Number: 5342

Control Panels:

spaTouch™3 Version 1.02 and later

spaTouch™2 Any version (version 2.0 or later required for bba™2 fully integrated functionality; version 2.19 or later required for CHROMAZON∃™ support)

Icon spaTouch™ Any version (version 3.36 or later required for bba™2 fully integrated functionality)

Menued spaTouch[™] Any version (version 2.8 or later required for bba[™]2 integrated functionality)

TP900 Version 3.1 and later (Version 3.13 or later required for bba™)

TP800 Version 3.1 and later (Version 3.13 or later required for bba™; version 4.11 or later required for bba™2 integrated functionality)

TP600 Version 2.7 and later (Version 2.12 or later required for bba™/bba™2 On/Off control via menu)

TP500 Any version -- Note: The TP500 works in the same Setups in which the TP400T works; see the TP400 page for defails

TP400T US Version 2.7 and later (TP400T CE may be used) (Version 2.12 or later required for bba™/bba™2 On/Off control via menu)

TP400W US Version 2.7 and later (TP400W CE may be used) (Version 2.12 or later required for bba™/bba™2 On/Off control via menu)



System Revision History

Part #	EPN	Date	Originator	Changes Made
G4361 G5361	5342	03-11-20	BWG	Stripped-down version of BP2000 board, with no remote support, no real-time clock, & no low speed relay for Pump 2, named the BP1800 board. Generic BP7 system for aftermarket use, based on this board, with 32 Setups.

bba™ & bba™2 (Balboa Bluetooth Amp) connection is documented seperately.

bba[™] is integrated into graphic display panels (TP800, TP900 and spaTouch[™]). With TP600/TP500/TP400, use the "BT" entry on the menu to toggle bba[™] power On/Off. bba[™]2 is integrated into graphic display panels (TP800, TP900 and spaTouch[™]). With TP600/TP500/TP400, use the "BT" entry on the menu to toggle bba[™]2 power On/Off.

Template 56377 10-05-12 2 G4361_G5361_97_A 03-31-20

Basic Functions Setup 1-32

Power Requirements:

240VAC, 50/60Hz*, 48A, Class A GFCI-protected service (Circuit Breaker = 60A max.), 4 wires [hot, hot, neutral, ground]
240VAC "dedicated", 50/60Hz*, 48A, Class A GFCI-protected service (Circuit Breaker = 60A max.), 3 wires [hot, hot, ground]

* BP systems automatically detect 50Hz vs 60Hz. However, power frequency (50Hz vs 60Hz) is just one of many differences between North American (UL) and CE power, and it is because of these other differences that different BP systems must be used for UL vs CE territories. Also, there are a few countries that use CE power but 60 Hz (such as South Korea) which need CE systems, and a few countries that use UL power but 50 Hz which need UL systems.

HiPot Testing Note:

Disconnect slip terminal with green wires from J11 prior to performing HiPot test. Failure to disconnect may cause a false failure of the test. Reconnect terminal to J11 after successful completion of HiPot test.



Template 56377 10-05-12 3 G4361_G5361_97_A 03-31-20

Basic Functions Setup 1-32

System Ouputs:

Pump 1	240VAC	2-Speed 1-Speed in	12A max Setups 3, 5, 11, 1	15-minute timer for High Speed, 15-Minute timer for Low 14, 16, 24, 26 & 31	Speed
		•	in Setups 6–8, 17		
Pump 2	240VAC	•	Setups 2, 3, 7, 10	15-minute timer), 11, 13, 14, 18, 20, 23, 24, 28 & 30-32 , 16, 21, 25, 26 & 29	
Pump 3	240VAC	1-Speed Unused in S	12A max Setups 1-8, 12-16	15-minute timer & 19-29	
Pump 4	240VAC	1-Speed Unused in S	10A† max Setups 1-29	15-minute timer	
Blower	240VAC	1 Speed Unused in S	4A max Setups 9-32	15-minute timer	
MicroSilk®	240VAC	1-Speed Used in Set	8A max* ups 22-29 only	30-minute timer	MicroSilk® is a registered trademark of Jason International
Circ Pump		1-Speed heater pump r 20 GPM thro	•	Programmable Filtration Cycles + Polling 16, 22-26, 30 & 31	
0zone	240VAC**		.5A max	Slaved to Circ Pump in Setups 1–5, 9-16, 22-26, 30 & 31 Independent in Setups 6–8, 17-21, 27-29 & 32	
Spa Light	10VAC	0n/0ff	2A* max	240-minute timer.	
A/V (Stereo) Heater) 240VAC*** 5.5kW @ 24	Hot 60VAC	2A max	Always on	
Heatel	4.0kW @ 24				

^{**} Both the Circ pump and Ozone can be converted to 120V, however they will be the same voltage after conversion. (Both 120V or both 240V.)



^{***} A/V can be converted to 120V, however it may require more than 2A at 120V, in which case the pump amperages may need to be scaled back, especially in the 4-pump Setups 30-32.


[†] In Setups 30-32, where pump 2 and pump 4 are both on the expander board, pump 2 and pump 4 <u>must</u> add up to <u>no more than</u> 20A <u>total</u>. The above limits are for a 48A service (60A breaker). If using a smaller service, smaller maximums may be required, depending on the Setup.

^{* 2}A max limit is shared by On/Off Spa Light <u>and</u> CHROMAZON∃™.

Hardware Setup

Wiring Diagram

Template 56377 10-05-12



Manufactured under one or more of these patents. U.S. Patents: 5332944, 5361215, 5550753, 5559720, 5,883,459, 6253227, 6282370, 6590188, 6976052, 6965815, 7030343, 7,417,834 b2, Canadian Patent: 2342614, Australian patent: 2373248 other patents both foreign and domestic applied for and pending.



Hardware Setup

Settings

2	PROGRAMMABLE FILTRATION + POLLING							SCALE
2		2-SPEED	2-SPEED	NONE	NONE	1-SPEED	NONE	°F
	PROGRAMMABLE FILTRATION + POLLING	2-SPEED	1-SPEED	NONE	NONE	1-SPEED	NONE	°F
3	PROGRAMMABLE FILTRATION + POLLING	1-SPEED	1-SPEED	NONE	NONE	1-SPEED	NONE	°F
4	PROGRAMMABLE FILTRATION + POLLING	2-SPEED	NONE	NONE	NONE	1-SPEED	NONE	°F
5	PROGRAMMABLE FILTRATION + POLLING	1-SPEED	NONE	NONE	NONE	1-SPEED	NONE	°F
6	NONE	2-SPEED	2-SPEED	NONE	NONE	1-SPEED	NONE	°F
7	NONE	2-SPEED	1-SPEED	NONE	NONE	1-SPEED	NONE	°F
8	NONE	2-SPEED	NONE	NONE	NONE	1-SPEED	NONE	°F
9	PROGRAMMABLE FILTRATION + POLLING	2-SPEED	2-SPEED	1-SPEED	NONE	NONE	NONE	°F
10	PROGRAMMABLE FILTRATION + POLLING	2-SPEED	1-SPEED	1-SPEED	NONE	NONE	NONE	°F
11	PROGRAMMABLE FILTRATION + POLLING	1-SPEED	1-SPEED	1-SPEED	NONE	NONE	NONE	°F
12	PROGRAMMABLE FILTRATION + POLLING	2-SPEED	2-SPEED	NONE	NONE	NONE	NONE	°F
13	PROGRAMMABLE FILTRATION + POLLING	2-SPEED	1-SPEED	NONE	NONE	NONE	NONE	°F
14	PROGRAMMABLE FILTRATION + POLLING	1-SPEED	1-SPEED	NONE	NONE	NONE	NONE	°F
15	PROGRAMMABLE FILTRATION + POLLING	2-SPEED	NONE	NONE	NONE	NONE	NONE	°F
16	PROGRAMMABLE FILTRATION + POLLING	1-SPEED	NONE	NONE	NONE	NONE	NONE	°F
17	NONE	2-SPEED	2-SPEED	1-SPEED	NONE	NONE	NONE	°F
18	NONE	2-SPEED	1-SPEED	1-SPEED	NONE	NONE	NONE	°F
19	NONE	2-SPEED	2-SPEED	NONE	NONE	NONE	NONE	°F
20	NONE	2-SPEED	1-SPEED	NONE	NONE	NONE	NONE	°F
21	NONE	2-SPEED	NONE	NONE	NONE	NONE	NONE	°F
22	PROGRAMMABLE FILTRATION + POLLING	2-SPEED	2-SPEED	NONE	NONE	NONE	1-SPEED	°F
23	PROGRAMMABLE FILTRATION + POLLING	2-SPEED	1-SPEED	NONE	NONE	NONE	1-SPEED	°F
24	PROGRAMMABLE FILTRATION + POLLING	1-SPEED	1-SPEED	NONE	NONE	NONE	1-SPEED	°F
25	PROGRAMMABLE FILTRATION + POLLING	2-SPEED	NONE	NONE	NONE	NONE	1-SPEED	°F
26	PROGRAMMABLE FILTRATION + POLLING	1-SPEED	NONE	NONE	NONE	NONE	1-SPEED	°F
27	NONE	2-SPEED	2-SPEED	NONE	NONE	NONE	1-SPEED	°F
28	NONE	2-SPEED	1-SPEED	NONE	NONE	NONE	1-SPEED	°F
29	NONE	2-SPEED	NONE	NONE	NONE	NONE	1-SPEED	°F
30‡	PROGRAMMABLE FILTRATION + POLLING	2-SPEED	1-SPEED	1-SPEED	1-SPEED	NONE	NONE	°F
31‡	PROGRAMMABLE FILTRATION + POLLING	1-SPEED	1-SPEED	1-SPEED	1-SPEED	NONE	NONE	°F
32‡	NONE	2-SPEED	1-SPEED	1-SPEED	1-SPEED	NONE	NONE	°F

---- INSTEAD OF SETUP #21. THIS SYSTEM IS CONFIGURED IN

SETUP #:

‡SETUPS 30-32 REQUIRE SPLITTER PN 25801



BP7 - PN G4361



03-24-20

CONNECT ONLY TO CIRCUITS PROTECTED BY A CLASS A GFCI.

A DISCONNECTING MEANS MUST BE INSTALLED WITHIN SIGHT FROM THE EQUIPMENT AND AT LEAST 5 FEET (1.52 M) FROM THE INSIDE WALLS OF THE POOL, SPA, OR HOT TUB.

TOTAL OUTPUT AMP DRAW NOT TO EXCEED MAX INPUT RATING OF SPA USE EARTH GROUND CONNECTIONS AS INDICATED INSIDE THE SYSTEM ENCLOSURE

TEST MODE OFF	⋖ A1	TEST MODE ON
DON'T ADD 1 HS PUMP W/HTR	A2 -	ADD 1 HS PUMP WITH HEAT
DON'T ADD 2 HS PUMPS W/HTR	⋖ A3	ADD 2 HS PUMPS WITH HEAT
DON'T ADD 4 HS PUMPS W/HTR	⋖ A4	ADD 4 HS PUMPS WITH HEAT
SPECIAL AMPERAGE RULE A	⋖ A5	SPECIAL AMPERAGE RULE B
STORE SETTINGS**	⋖ A6	MEMORY RESET**
1 MIN HTR COOLDOWN (ELEC)	⋖ A7	5 MIN HTR COOLDOWN (GAS)
NOT ASSIGNED	⋖ A8	NOT ASSIGNED
NOT ASSIGNED	⋖ A9	NOT ASSIGNED
NOT ASSIGNED	◀ A10	NOT ASSIGNED

^{**} SWITCH # 6 SHOULD BE SET TO OFF UPON FINAL INSTALLATION.


LOCATION	DEVICE	VOLTS	MAX AMPS	FROM	T0
J9	2-SP PUMP 1	240V	12A MAX	J46	GROUP 2
J14	1-SP BLOWER / 1-SP PUMP 3 / 1-SP MICROSILK®	240V	4A MAX / 12A MAX / 8A MAX	J18	GROUP 2
	J14 LINE 1 CO	NNECTION	FOR BLOWER	J43	J13
	J14 LINE 1 CO	NNECTION	FOR P3/MS	J43	J19
J15	SPA LIGHT	10V	2A*		
J21	CIRC PUMP	240V**	2A MAX	J20	GROUP 2
J32	OZONE		0.5A		
	CIRC AND OZON	E LINE 1	CONNECTION	J81	J59
J33	TV / AV	240V***	2A	J38	GROUP 2
J44	HEATER	240V	4.0 kW		

* 2A LIMIT IS SHARED BY J15 SPA LIGHT AND CHROMAZON∃™

** CIRC PUMP + OZONE CAN BE 120V IF J20 IS CONNECTED TO GROUP 4

*** AV CAN BE 120V IF J38 IS CONNECTED TO GROUP 4, BUT IN THAT CASE IT MAY REQUIRE MORE THAN 2A. IN WHICH CASE PUMP AMPERAGES MAY NEED TO BE SCALED BACK, ESPECIALLY IN THE 4-PUMP SETUPS 30-32

PART B





Setup Reference Table for Setups 1-16 (Setups 17-32 on next page)

Setup #	Circ Pump	Pump 1	Pump 2	Pump 3	Pump 4	Blower	MicroSilk®	Temp Scale
1	Programmable Filtration + Polling	2-Speed	2-Speed	None	None	1-Speed	None	°F
2	Programmable Filtration + Polling	2-Speed	1-Speed	None	None	1-Speed	None	°F
3	Programmable Filtration + Polling	1-Speed	1-Speed	None	None	1-Speed	None	°F
4	Programmable Filtration + Polling	2-Speed	None	None	None	1-Speed	None	°F
5	Programmable Filtration + Polling	1-Speed	None	None	None	1-Speed	None	°F
6	None	2-Speed	2-Speed	None	None	1-Speed	None	°F
7	None	2-Speed	1-Speed	None	None	1-Speed	None	°F
8	None	2-Speed	None	None	None	1-Speed	None	°F
9	Programmable Filtration + Polling	2-Speed	2-Speed	1-Speed	None	None	None	°F
10	Programmable Filtration + Polling	2-Speed	1-Speed	1-Speed	None	None	None	°F
11	Programmable Filtration + Polling	1-Speed	1-Speed	1-Speed	None	None	None	°F
12	Programmable Filtration + Polling	2-Speed	2-Speed	None	None	None	None	°F
13	Programmable Filtration + Polling	2-Speed	1-Speed	None	None	None	None	°F
14	Programmable Filtration + Polling	1-Speed	1-Speed	None	None	None	None	°F
15	Programmable Filtration + Polling	2-Speed	None	None	None	None	None	°F
16	Programmable Filtration + Polling	1-Speed	None	None	None	None	None	°F

Color Key	Output
	XP332
	XP332 and Splitter
	J14 (Aux) on Main Board



Template 56377 10-05-12 7 G4361_G5361_97_A 03-31-20

Setup Reference Table for Setups 17-32 (Setups 1-16 on previous page)

Setup #	Circ Pump	Pump 1	Pump 2	Pump 3	Pump 4	Blower	MicroSilk®	Temp Scale
17	None	2-Speed	2-Speed	1-Speed	None	None	None	°F
18	None	2-Speed	1-Speed	1-Speed	None	None	None	°F
19	None	2-Speed	2-Speed	None	None	None	None	°F
20	None	2-Speed	1-Speed	None	None	None	None	°F
21	None	2-Speed	None	None	None	None	None	°F
22	Programmable Filtration + Polling	2-Speed	2-Speed	None	None	None	1-Speed	°F
23	Programmable Filtration + Polling	2-Speed	1-Speed	None	None	None	1-Speed	°F
24	Programmable Filtration + Polling	1-Speed	1-Speed	None	None	None	1-Speed	°F
25	Programmable Filtration + Polling	2-Speed	None	None	None	None	1-Speed	°F
26	Programmable Filtration + Polling	1-Speed	None	None	None	None	1-Speed	°F
27	None	2-Speed	2-Speed	None	None	None	1-Speed	°F
28	None	2-Speed	1-Speed	None	None	None	1-Speed	°F
29	None	2-Speed	None	None	None	None	1-Speed	°F
30	Programmable Filtration + Polling	2-Speed	1-Speed	1-Speed	1-Speed	None	None	°F
31	Programmable Filtration + Polling	1-Speed	1-Speed	1-Speed	1-Speed	None	None	°F
32	None	2-Speed	1-Speed	1-Speed	1-Speed	None	None	°F

System (and any replacement board) is shipped in Setup 21

Color	Output
Key	
	XP332
	XP332 and Splitter
	J14 (Aux) on Main Board



Changing Software Setups with spaTouch™ Icon-Driven Panels

Test Menu Access (S1, Switch 1 ON) Service Technician ONLY.


DANGER! HIGH VOLTAGE WILL BE ACCESSIBLE! SERVICE TECHNICIAN ONLY!

While the system is running, move DIP Switch 1 (on S1 on the Main circuit board) to ON. The system will enter Test Mode.

Moving DIP Switch 1 to OFF will exit Test Mode.

10 S1


ON >




To Change Software Setups:

While in Test Mode, press the indicated icons to move from screen to screen.








The example screens shown here are from the

spaTouch 1 Icon-Driven Panel, but the screens on the spaTouch 2 Panel are similar. The main

difference is that the spaTouch 2 display is



Once on the Setup Selection screen, press the Up or Down icon to select the desired Setup Number, then press the Check Mark icon to confirm and to have the spa restart.

After the system restarts, you may see a message that "The settings have been reset"; this is normal after changing Setups with DIP Switch 6 in the OFF position. Press "Clear" to dismiss this message.



Manufactured under one or more of these patents. U.S. Patents: 5332944, 5361215, 5550753, 5559720, 5,883,459, 6253227, 6282370, 6590188, 6976052, 6965815, 7030343, 7,417,834 b2, Canadian Patent: 2342614, Australian patent: 2373248 other patents both foreign and domestic applied for and pending.



Changing Software Setups with TP800 / TP900 / spaTouch™ Menued Panel

Test Menu Access (S1, Switch 1 ON) Service Technician ONLY.


DANGER! HIGH VOLTAGE WILL BE ACCESSIBLE! SERVICE TECHNICIAN ONLY!


While the system is running, move DIP Switch 1 (on S1 on the Main circuit board) to ON. The system will enter Test Mode.

Moving DIP Switch 1 to OFF will exit Test Mode.

Software Setups

Under the TEST Menu, the Setup screen will allow changing the Setup from 1 to any number established by the Manufacturer. Changing the Setup may require wiring changes as well.







Changing Software Setups with TP600 / TP500 / TP400

Test Menu Access (S1, Switch 1 ON) Service Technician ONLY.

DANGER! HIGH VOLTAGE WILL BE ACCESSIBLE! SERVICE TECHNICIAN ONLY!

While the system is running, move DIP Switch 1 (on S1 on the Main circuit board) to ON. The system will enter Test Mode.

Moving DIP Switch 1 to OFF will exit Test Mode.

As soon as Switch #1 is placed in the ON position, the temperature will show "T" after it instead of F or C, indicating the System is in Test Mode

Software Setups

Under the TEST Menu, the Setup screen will allow changing the Setup from 1 to any number established by the Manufacturer. Changing the Setup may require wiring changes as well.

You will have 1 minute to complete the setup change after you manually exit Priming Mode. (Once familiar with the process, the Setup change should take less than 15 seconds.)











When the panel displays RUN PMPS PURG AIR, press any Temperature button ONCE to exit Priming Mode. You should see "---T" where the T indicates the system is in Test Mode.



Continued on Next Page.



Changing Software Setups with TP600 / TP500 / TP400 Continued

Again, You will have 1 minute to complete the setup change after you manually exit Priming Mode.


NOTE: WHerever the below says Warm or Temp followed by Light, on the TP500 press Menu instead of Warm or Temp followed by light. And whenever the chart below says Light, on the TP500 press Menu insead of Light.

Immediately after exiting Priming Mode, press this sequence of buttons: Warm*, Light, Warm, Warm, Warm, Warm. Continue to press Warm until the diplay shows the Setup Number (S-01, S-02, etc.) you want to switch to. When the correct setup number is showing, press Light once, and the system will reset, using the newly-selected Setup from that point on.

Move DIP Switch 1 to the OFF position to take the spa out of Test Mode. °F or °C will replace °T.

Using a permanent marker, write the Setup number on the Setup label mounted inside the system lid (right). This is very important to any service person in the future who may need to replace a circuit board or system and needs to change the Setup on a replacement part while in the field.

NOTE: Changing the Setup may require wiring changes as well - refer to the wiring diagram or wiring diagram addendum.



Manufactured under one or more of these patents. U.S. Patents: 5332944, 5361215, 5550753, 5559720, 5,883,459, 6253227, 6282370, 6590188, 6976052, 6965815, 7030343, 7,417,834 b2, Canadian Patent: 2342614, Australian patent: 2373248 other patents both foreign and domestic applied for and pending. © Copyright 2009 Balboa Water Group.



THIS SYSTEM IS

CONFIGURED AS SETUP #

Template 56377 10-05-12 12 G4361_G5361_97_A 03-31-20

Equipment Expansion

Expansion Features Control Connection

Relay 1 (J101) Relay 7/8 (J107)

Default	Fuse
Undefined	None
See Below	30A

2-Speed Pump 2 in Setups 1, 6, 9, 12, 17, 19, 22 & 27 1-Speed Pump 2 (only) in Setups 2, 3, 7, 10, 11, 13, 14, 18, 20, 23, 24 & 28 1-Speed Pump 2 And 1-Speed Pump 4 (With Splitter) in Setups 30-32 Unused in Setups 4, 5, 8, 15, 16, 21, 25, 26 & 29



DIP Switch Functions

Fixed-fuction DIP Switches

A1 Test Mode (normally Off).

A2 In "ON" position, add one high-speed pump (or blower) with Heater.

A3 In "ON" position, add two high-speed pumps (or 1 HS Pump and Blower) with Heater.

A4 In "ON" position, add four high-speed pumps (or 3 HS Pumps and Blower) with Heater.

A5 In "ON" position, enables Special Amperage Rule B. See Special Features section under Configuration Options for functionality with your system.

In "OFF" position, enables Special Amperage Rule A.

A6 Persistent memory reset (Used when the spa is powering up to restore factory settings as determined by software configuration).

A2, A3, and A4 work in combination to determine the number of high-speed devices and blowers that can run before the heat is disabled. i.e. A2 and A3 in the ON position and A4 in the OFF position will allow the heater to operate with up to 3 high-speed pumps (or two HS Pumps and Blower) running at the same time. Heat is disabled when the fourth high-speed pump or blower is turned on.

Note: A2/A3/A4 all off = No heat with any high-speed pump or blower.

Assignable DIP Switches

A7 In "ON" position, enables a 5-minute cooldown for some gas heaters (Cooling Time B).

In "OFF" position, enables a 1-minute cooldown for electric heaters (Cooling Time A).

Undesignated switches are not assigned a function.



Jumper Definitions

J109	GFCI Test/Trip Enable/Disable	1100 (-
	Note: This feature must be enabled in software as well.	J109 🚰
J91	Not used on BP1800 board.	
J30	Do Not Use	
J31	Not used on BP1800 board.	
J29	Heater Disable Switch Connection. If J29 is shorted by any means, the heater will not run until J29 is no longer shorted.	J29 👸
	If J29 is shorted during power-up "J29" will appear on the panel. The message can be dismissed with a button press, and is the only control panel notification of J29 being shorted. No message is displayed if J29 is shorted after power-up, but the heater will not run until J29 is no longer shorted.	[2]
	J29 expects a switch closure (not a voltage) as the command signal.	
	In some areas, a local power company may offer discounts based on voluntary "power shedding" devices that may be installed in	n conjunction with the spa.
J25, J26, J27	Not used on BP1800 board.	
	Note: Factory Configured do not change.	
 J24	Jumper on center two pins (230V) when heater is running at 240V.	230V
	Two Jumpers installed; one on left 2 pins and one on right 2 pins (115V) when heater is running at 120V.	J24 0 0 0 115 15V

Warning!

Setting DIP switches or jumpers incorrectly may cause abnormal system behavior and/or damage to system components. Refer to Switchbank illustration on Wiring Configuration page for correct settings for this system. Contact Balboa if you require additional configuration pages added to this tech sheet.

Manufactured under one or more of these patents. U.S. Patents: 5332944, 5361215, 5550753, 5559720, 5,883,459, 6253227, 6282370, 6590188, 6976052, 6965815, 7030343, 7,417,834 b2, Canadian Patent: 2342614, Australian patent: 2373248 other patents both foreign and domestic applied for and pending.



15 G4361_G5361_97_A 03-31-20

Replacement Parts

PCBA:

Main PCBA: G1361 Expander PCBA: 59097

HEATER(s):

Plug + Click Heater Kit: G7512 5.5kW 800Inc

G7412 4.0kW 800Inc

Temp Sensor Kit: 53605

CABLES: N/A

FUSES:

Part Number	Amperage	Location		
30136	30A	F6, F8, F1 (Expander)		
26307	2A SLO	F4		
26905	0.5A SL0	F3		
26904	10A	F2, F7		
26976	3.15A SL0	F5		

General Features

Feature	Default
Pump 1 in Filter Cycle (Circ Only)	No
Pump 1 Low Timer	15 Minutes
General Pump Timer	15 Minutes
Blower Timer	15 Minutes
Mister Timer	15 Minutes
Light Timer	240 Minutes
Circ (when enabled)	Programmable + Polling
	20 Minutes
Cleanup Cycle	30 Minutes
Cleanup as Draference setting	Vos

Cleanup as Preference setting Yes

Ozone With Heater Pump*

Ozone Suppression OFF

Pump Purge60 SecondsBlower Purge30 SecondsMister Purge5 Seconds

Purge Type Serial - Pumps at lowest speed



 $[\]ensuremath{^{\star}}$ The heater Pump can be either a Circ Pump or Pump 1 Low.

Temperature Features

Feature Display PF

All temperatures must be specified in °F. The system converts °F to °C dynamically. If Celsius is required for default settings, choose a desired °C value that (after rounding) corresponds to a Fahrenheit value.

°C	4	5	6	7	8	9	<i>10</i>	11	12	13	14	15	<i>16</i>	17	18	19	20	21	22	
°F	39	41	43	45	46	48	50	52	54	55	57	59	61	63	64	66	68	70	72	
°C	23	24	25	26	27	28	29	30	31	<i>32</i>	33	34	<i>35</i>	36	37	38	39	40		
°F	73	<i>75</i>	77	79	81	82	84	86	88	90	91	93	95	97	99	100	102	104		

Hi-Range Min. Set Temp	80°F
Hi-Range Max. Set Temp	104°
Hi-Range Default Temp*	100°
Lo-Range Min. Set Temp	50°F
Lo-Range Max. Set Temp	99°F
Lo-Range Default Temp*	70°F
Freeze Threshold	44°F

Freeze Type Rotating - Pumps at Lowest Speed

Temp Lock Type Temp + Settings

BALB@A
water group

^{*}May be changed by end-user (if enabled)

Time Features

Feature	Default
Time Format*	12 Hour
Filter 1 Start Hour*	20:00 (8:00 PM)
Filter 1 Duration*	2 Hours
Filter Cycle 2 Default*	OFF
Filter 2 Start Hour*	08:00 (8:00 AM)
Filter 2 Duration*	15 Minutes
Light Cycle	Disabled
Light Cycle Default*	OFF
	•
Light Cycle Start Hour*	21:00 (9:00 PM)
Light Cycle Duration*	15 Minutes
Cooling Time A	1 Minute
Cooling Time B	5 Minutes

BALB@A

^{*}May be changed by end-user (if enabled)

Reminder Features

Feature	Default
Reminders Shown*	Yes
Check pH	0FF
Check Sanitizer	0FF
Clean Filter	30 Days
Test GFCI	65 Days
Drain Water	100 Days
Change Cartridge	OFF
Clean Cover	<i>OFF</i>
Treat Wood	<i>OFF</i>
Change Filter	365 Days

BALB (A) Water group

^{*}May be changed by end-user (if enabled)

Special Features Feature

Default

Special Amperage Rule A Special Amperage Rule B MicroSilk® immediately turns OFF pumps in Setups 22-29; No Limitation in other Setups

MicroSilk® immediately turns OFF pumps in Setups 22-29; 3 high-speed pumps maximum in Setups 30-32;

2 high-speed pumps maximum and blower suppressed when 2 pumps are on high-speed, in other Setups

Drain Mode Disabled
Demo Mode Disabled
GFCI Trip Enabled
Automatic GFCI Test Disabled

Ozone Slaved to Heater Pump

Dual Voltage Heater

Safety Suction

Yes in circ setups

No in non-circ setups

Always Input Voltage

Disabled

TP900 Panel Configuration


Button Layout Table

Button #	Pump 3 AND Pump 4	Pump 3 (no Pump 4)	Blower + Pump 2 Setups 1-3, 6 & 7	Blower (no Pump 2)	MicroSilk® + Pump 2	MicroSilk® (no Pump 2)	Pump 2 (no P3/ BL/MS)	Pump 1 (no P2/ BL/MS)
	Setups 30-32	Setups 9-11, 17 & 18	, .	Setups 4, 5 & 8	Setups 22-24, 27 & 28	Setups 25, 26 & 29	Setup 12-14, 19 & 20	Setup 15, 16 & 21
1	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A
2	Jets 1	Jets 1	Jets 1	Jets 1	Jets 1	Jets 1	Jets 1	Jets 1
3	Jets 2	Jets 2	Jets 2	Blower	Jets 2	MicroSilk®	Jets 2	Light 1
4	Jets 3	Jets 3	Blower	Light 1	MicroSilk®	Light 1	Light 1	Invert
5	Jets 4	Light 1	Light 1	Invert	Blower	Invert	Invert	(Circ Icon)
6	Light 1	Invert	Invert	(Circ Icon)	Light 1	(Circ Icon)	(Circ Icon)	Undefined
7	Invert	(Circ Icon)	(Circ Icon)	Undefined	Invert	Undefined	Undefined	Undefined
8	(Circ Icon*)	Undefined	Undefined	Undefined	(Circ Icon)	Undefined	Undefined	Undefined
9	Undefined	Undefined	Undefined	Undefined	Undefined	Undefined	Undefined	Undefined
10	Undefined	Undefined	Undefined	Undefined	Undefined	Undefined	Undefined	Undefined
11	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A
12	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A
13	Jets 1	Jets 1	Jets 1	Jets 1	Jets 1	Jets 1	Jets 1	Jets 1
14	Jets 2	Jets 2	Jets 2	Blower	Jets 2	Undefined	Jets 2	Undefined
15	Jets 3	Jets 3	Blower	Light	MicroSilk®	MicroSilk®	Light	Light
16	Light	Light	Light	Invert	Light	Light	Invert	Invert

^{*} A Circ Icon will appear in Circ Setups 1–5, 9-16, 22-26, 30 & 31; it will not appear in non-Circ Setups 6–8, 17-21, 27-29 & 32.



TP900 Panel Configuration



TP800 Panel Configuration

Button Layout Table

Feature #	Pump 3 AND Pump 4	Pump 3 (no Pump 4)	Blower + Pump 2 Setups 1-3, 6 & 7	Blower (no Pump 2)	MicroSilk® + Pump 2	MicroSilk® (no Pump 2)	Pump 2 (no P3/ BL/MS)	Pump 1 (no P2/ BL/MS)
	Setups 30-32	Setups 9-11, 17 & 18		Setups 4, 5 & 8	Setups 22-24, 27 & 28	Setups 25, 26 & 29	Setup 12-14, 19 & 20	Setup 15, 16 & 21
A1	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A
A2	Jets 1	Jets 1	Jets 1	Jets 1	Jets 1	Jets 1	Jets 1	Jets 1
А3	Jets 2	Jets 2	Jets 2	Blower	Jets 2	MicroSilk®	Jets 2	Light 1
A4	Jets 3	Jets 3	Blower	Light 1	MicroSilk®	Light 1	Light 1	Invert
A5	Jets 4	Light 1	Light 1	Invert	Blower	Invert	Invert	(Circ Icon)
A6	Light 1	Invert	Invert	(Circ Icon)	Light 1	(Circ Icon)	(Circ Icon)	Undefined
A7	Invert	(Circ Icon)	(Circ Icon)	Undefined	Invert	Undefined	Undefined	Undefined
A8	(Circ Icon*)	Undefined	Undefined	Undefined	(Circ Icon)	Undefined	Undefined	Undefined
A9	Undefined	Undefined	Undefined	Undefined	Undefined	Undefined	Undefined	Undefined
A10	Undefined	Undefined	Undefined	Undefined	Undefined	Undefined	Undefined	Undefined
A11	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A
A12	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A
A13	Jets 1	Undefined	Undefined	Undefined	Undefined	Undefined	Undefined	Undefined
A14	Jets 2	Undefined	Undefined	Undefined	Undefined	Undefined	Undefined	Undefined
A15	Jets 3	Undefined	Undefined	Undefined	Undefined	Undefined	Undefined	Undefined
A16	Jets 4	Undefined	Undefined	Undefined	Undefined	Undefined	Undefined	Undefined
B1	Jets 1	Jets 1	Jets 1	Jets 1	Jets 1	Jets 1	Jets 1	Jets 1
В2	Jets 2	Jets 2	Jets 2	Blower	Jets 2	Undefined	Jets 2	Undefined
В3	Jets 3	Jets 3	Blower	Undefined	MicroSilk®	MicroSilk®	Undefined	Undefined
B4	Light	Light	Light	Light	Light	Light	Light	Light


^{*} A Circ Icon will appear in Circ Setups 1–5, 9-16, 22-26, 30 & 31; it will not appear in non-Circ Setups 6–8, 17-21, 27-29 & 32.


Manufactured under one or more of these patents. U.S. Patents: 5332944, 5361215, 5550753, 5559720, 5,883,459, 6253227, 6282370, 6590188, 6976052, 6965815, 7030343, 7,417,834 b2, Canadian Patent: 2342614, Australian patent: 2373248 other patents both foreign and domestic applied for and pending.




TP800 Panel Configuration


Spa Screen









Shortcuts Screen







Note: Buttons 11 and 12 are not used in this configuration.

Button 1 is fixed.




TP600 Panel Configuration

Button Layout Table

Button #	Pump 3 AND Pump 4	Pump 3 (no Pump 4)	Blower + Pump 2	Blower (no Pump 2)	MicroSilk® + Pump 2	MicroSilk® (no Pump 2)	Pump 2 (no P3/BL/MS)	Pump 1 (no P2/BL/MS)
	Setups 30-32	Setups 9-11, 17 & 18	Setups 1-3, 6 & 7	Setups 4, 5 & 8	Setups 22-24, 27 & 28	Setups 25, 26 & 29	Setup 12-14, 19 & 20	Setup 15, 16 & 21
1	Jets 1	Jets 1	Jets 1	Jets 1	Jets 1	Jets 1	Jets 1	Jets 1
2	Jets 2	Jets 2	Jets 2	Blower	Jets 2	MicroSilk®	Jets 2	Unused
3	Jets 3	Jets 3	Blower	Invert	MicroSilk®	Invert	Invert	Invert
4	Temperature	Up	Up	Up	Up	Up	Up	Up
5	Light 1	Light 1	Light 1	Light 1	Light 1	Light 1	Light 1	Light 1
6	Jets 4	Down	Down	Down	Down	Down	Down	Down
LED 1	Jets 1	Jets 1	Jets 1	Jets 1	Jets 1	Jets 1	Jets 1	Jets 1
LED 2	Jets 2	Jets 2	Jets 2	Blower	Jets 2	MicroSilk®	Jets 2	Unused
LED 3	Light 1	Light 1	Light 1	Light 1	Light 1	Light 1	Light 1	Light 1
LED 4	Heat On	Heat On	Heat On	Heat On	Heat On	Heat On	Heat On	Heat On
eneric Overlay	13579	12762	12762	12101	13142	12740	12198*	13635*

^{*} Overlay 12101 can also be used



Manufactured under one or more of these patents. U.S. Patents: 5332944, 5361215, 5550753, 5559720, 5,883,459, 6253227, 6282370, 6590188, 6976052, 6965815, 7030343, 7,417,834 b2, Canadian Patent: 2342614, Australian patent: 2373248 other patents both foreign and domestic applied for and pending.




Template 56377 10-05-12 26 G4361_G5361_97_A 03-31-20

TP400 Panel Configuration

Button Layout Table for TP400T TP400T is not supported in Setups 1-3, 6, 7, 9-11, 17, 18, 22-24, 27, 28 & 30-32.

Button #	Setups 4, 5, & 8	Setups 12-14, 19 & 20	Setups 15, 16 & 21	Setups 25, 26 & 29
1	Temperature	Temperature	Temperature	Temperature
2	Jets 1	Jets 1	Jets 1	Jets 1
3	Light 1	Light 1	Light 1	Light 1
4	Blower	Jets 2	Undefined	MicroSilk®
LED 1	Heater ON	Heater ON	Heater ON	Heater ON
LED 2	Jets 1 ON	Jets 1 ON	Jets 1 ON	Jets 1 ON
LED 3	Light ON	Light ON	Light ON	Light ON
LED 4	Blower ON	Jets 2 ON	Undefined	MicroSilk® ON



TP400T US

50380-XX

Includes overlay PN 12511.

Button Layout Table for TP400W

1 Up 2 Down 3 Light 1 4 Jets 1 LED 1 Heater ON LED 2 Undefined LED 3 Light ON	Button #	All Setups
3 Light 1 4 Jets 1 LED 1 Heater ON LED 2 Undefined LED 3 Light ON	1	Up
4 Jets 1 LED 1 Heater ON LED 2 Undefined LED 3 Light ON	2	Down
LED 1 Heater ON LED 2 Undefined LED 3 Light ON	3	Light 1
LED 2 Undefined LED 3 Light ON	4	Jets 1
LED 3 Light ON	LED 1	Heater ON
	LED 2	Undefined
ICD / John 1 ON	LED 3	Light ON
LED 4 Jets 1 ON	LED 4	Jets 1 ON

TP400W is supported in Setups 15, 16 & 21 only.

TP400W US

50384-XX

Includes overlay PN 12510.

Auxiliary Panel Features on Bank 1*

Feature	Default
Aux Button A1	Jets 1
Aux Button A2	Jets 2
Aux Button A3	Jets 3 in Setups 9-11, 17, 18 & 30-32; MicroSilk® in Setups 22-29; Blower in all other Setups
Aux Button A4	Light

*Bank 1 consists of J5 on the Main Circuit Board.

Aux Connection Splitter PN 25257 may be required.

Buttons that are assigned to equipment that is not defined in a Setup will not do anything in that Setup.



Auxiliary Panel Features

AX10 Panels on Bank 1*

A1, AX10A1 No 0/L 52803
A2, AX10A2 No 0/L 52804
A3, AX10A3 No 0/L 52805 ►
A4, AX10A4 No 0/L 52806




Call Customer Service for additional information about Auxiliary Panels.

*Bank 1 consists of J5 on the Main Circuit Board.

Aux Connection Splitter PN 25257 may be required.

AX20


AX20 A1A2 No 0/L 52800 AX20 A1A3 No 0/L 52801 AX20 A1A4 No 0/L 52802



AX20 Auxiliary Panel plugged into Bank 1 will operate A1 + A2, A3 or A4.

AX40

AX40 No 0/L 52799



AX40 Auxiliary Panel plugged into Bank 1 will operate A1 + A2, A3 and A4.



29